



PREP
 CONCRETE DECKS MUST BE MADE REASONABLE SMOOTH, DRY, FREE OF DIRT, LAITANCE, CURING AGENTS, DEBRIS AND OTHER CONTAMINANTS.

PRIME
 PRIME MASONRY/CONCRETE SURFACES AND ALLOW TO DRY BEFORE INSTALLING THE FLASHING SYSTEM.

RT250 - System Information

RT-250 HRA- 90 mils (min.)

Starting at the low points of the deck, apply a base coat of RamTough 250 no less than 90 mils thick and approximately 44" wide.

PolyFelt 125 VP Reinforcement

While still hot, install one ply of PolyFelt 125 VP reinforcement fabric into the RamTough 250. Standing off to the side, use a broom or squeegee to press the fabric into the hot bitumen

RT- 250 HRA -125 mils (min.)

After the base coat of waterproofing and reinforcement have been completed, apply a top coat of RamTough 250, applied at a minimum thickness of 125 mils.

RT250 - Additional Product Information and Components

Ram Tough Primer/ Surface Conditioner

Ram Flash 327 HDR

Ram Protection Course (Ram 203,306,306FR)

BUTYL OR POLYURETHANE SEALANT
 Ram Mastic, Keene Seal or Liquid Flash 100

RamDrain Drainage Mat

www.BarrettRoofs.com
 : 1-800-647-0100



DRAWN BY: LDS	SYSTEM: RT-250
DATE: 7.16.2024	CATAGORY: PT PARAPET BASE FLASHING OVERBURDEN
DETAIL NAME: BASE AND WALL FLASHING AT NON-MONOLITHIC MASONRY WALL	DETAIL #: RT250-PT-04