



PREP
 CONCRETE DECKS MUST BE MADE REASONABLE SMOOTH, DRY, FREE OF DIRT, LAITANCE, CURING AGENTS, DEBRIS AND OTHER CONTAMINANTS.

PRIME
 PRIME MASONRY/CONCRETE SURFACES AND ALLOW TO DRY BEFORE INSTALLING THE FLASHING SYSTEM.

CLEAN
 ALL PIPE PENETRATIONS (METAL OR PVC) SHOULD BE CLEANED AND FREE FROM ANY SURFACE CONTAMINANTS OR RUST.

MEASURE
 ALL PIPES SHOULD BE A MINIMUM OF 8 INCHES AWAY FROM WALLS, CURBS AND OTHER PIPES UNLESS A CHASE CURB IS USED.

RT250 - System Information

RT-250 HRA- 90 mils (min.) Starting at the low points of the deck, apply a base coat of RamTough 250 no less than 90 mils thick and approximately 44" wide.

PolyFelt 125 VP Reinforcement While still hot, install one ply of PolyFelt 125 VP reinforcement fabric into the RamTough 250. Standing off to the side, use a broom or squeegee to press the fabric into the hot bitumen.

RT- 250 HRA -125 mils (min.) After the base coat of waterproofing and reinforcement have been completed, apply a top coat of RamTough 250, applied at a minimum thickness of 125 mils.

RT250 - Additional Product Information and Components

Ram Tough Primer/ Surface Conditioner

Ram Flash 327 HDR

Ram Protection Course (Ram 203,306,306FR)

BUTYL OR POLYURETHANE SEALANT Ram Mastic, Keene Seal or Liquid Flash 100

RamDrain Drainage Mat



www.BarrettRoofs.com
 : 1-800-647-0100

DRAWN BY: LDS	SYSTEM: RT-250
DATE: 7.16.2024	CATAGORY: PE
DETAIL NAME: METAL VENT PIPE FLASHING	DETAIL #: RT250-PE-03