





PREP  CONCRETE DECKS MUST BE MADE REASONABLE SMOOTH, DRY, FREE OF DIRT, LAITANCE, CURING AGENTS, DEBRIS AND OTHER CONTAMINANTS.

PRIME  PRIME MASONRY/CONCRETE SURFACES AND ALLOW TO DRY BEFORE INSTALLING THE FLASHING SYSTEM.



RT250 - System Information

RT-250 HRA- 90 mils (min.)  90MILS 

Starting at the low points of the deck, apply a base coat of RamTough 250 no less than 90 mils thick and approximately 44" wide.


PolyFelt 125 VP Reinforcement 


While still hot, install one ply of PolyFelt 125 VP reinforcement fabric into the RamTough 250. Standing off to the side, use a broom or squeegee to press the fabric into the hot bitumen


RT- 250 HRA -125 mils (min.)  125MILS 


After the base coat of waterproofing and reinforcement have been completed, apply a top coat of RamTough 250, applied at a minimum thickness of 125 mils.


RT250 - Additional Product Information and Components

Ram Tough Primer/ Surface Conditioner 

Ram Flash 327 HDR 

Ram Protection Course (Ram 203,306,306FR) 

BUTYL OR POLYURETHANE SEALANT Ram Mastic, Keene Seal or Liquid Flash 100 

RamDrain Drainage Mat 



www.BarrettRoofs.com
: 1-800-647-0100

DRAWN BY: LDS	SYSTEM: RT-250
DATE: 7.16.2024	CATAGORY:RD DRAINAGE GUTTER SCUPPER OVERBURDEN
DETAIL NAME: SCUPPER THROUGH PERFORATED GRAVEL STOP EDGE AND A GUTTER	DETAIL #: RT250-RD-03